

03041P2

RIB ATTACHING MACHINE

SVIT Machinery s.r.o.
tr. T. Bati 5263, 762 02 Zlín
Czech Republic
tel.: +420 577 523 713
fax: +420 577 523 704
svitmachinery@svitmachinery.com



RIB ATTACHING MACHINE

03041P2

The machine is used for goodyear welted footwear manufacture and serves for attaching of a rib to a lasting insole by cold cement. The machine is equipped with cement activation, fluent regulation of speed and rib cut-off.

Technical parameters:

Productivity	pair/h	350
Air operation pressure	MPa	0,4-0,6
Installed output	kW	3,4
Machine dimensions:	width	mm
	depth	mm
	height	mm
Machine weight	kg	100

NALEPOVACÍ STROJ ŽEBRA NA STÉLKU

03041P2

Stroj se používá při výrobě rámové obuvi a slouží k přilepení žebra na napínací stélku studeným lepidlem. Stroj je vybaven aktivací lepidla, plynulou regulací rychlosti a odříhlem žebra.

Technické parametry:

Produktivita	párů/h	350
Pracovní tlak vzduchu	MPa	0,4-0,6
Instalovaný výkon	kW	3,4
Rozměry stroje:	šířka	mm
	hloubka	mm
	výška	mm
Hmotnost stroje	kg	100

MÁQUINA PARA PEGAR COSTILLA A PLANTILLA

03041P2

La máquina se usa para la producción del calzado de goodyear welt y sirve para pegar la costilla a la plantilla. La máquina está equipada con la activación del pegamento, con la regulación corriente de la velocidad y con el corte de la costilla.

Parámetros técnicos:

Productividad	pares/h	350
Presión de trabajo del aire	MPa	0,4-0,6
Potencia instalada	kW	3,4
Dimensiones de la máquina:	ancho	mm
	hondura	mm
	altura	mm
Peso de la máquina	kg	100